


Parts Catalog

OT/ON - CT/CN 40/70/125 Amp


OTIII TRANSFER SWITCH



Printed in U.S.A.

Introduction

This catalog applies to the OTIII Spec G , H & J Transfer Switches as indicated below. Each illustrated part is identified by a reference number corresponding to the same reference number in the parts list for that group. Parts illustrations are typical. Using the model and spec number from the switch box nameplate, select the parts that apply to your automatic transfer switch. Unless otherwise noted in the parts description, parts are interchangeable between models.



Feature Options can be determined by reading them off the nameplate or by accessing the following screen through the Distributor On–Line computer system. Note that the first digit typed on this screen is a code number corresponding to an individual Onan product (1=Engines, 2=Gensets, 5=Generator Ends, 6=LT's, 7=OT's/BT's) and that the spec number is always kept to the right and zero filled if the spec number is less than five digits.

ITEM N	IO: 702835
	•••••
A015 A029	260 Amps Continuous 4 Pole Switch for Program
A035	Utility to Genset
A042	Three Phase (3 or 4 Wire)

A044 60 Hz Frequency

A046 UL Listed

MADO

Index

Actuator, Linear, 4	Edging, 20
Adhesive, 20	Fuse, 26 , 28 , 30
Arm, Interlock, 6	Gasket, Cover - Meter, 20
Bar, Bus – Jumper, 5	Gasket, Door, 20
Bar, Bus – Load, 5	Handle Assembly, Actuator, 6, 8
Bar, Cross, 6	Handle, Door, 18
Bar, Interlock, 5	Handle, Switch, 8
Bar, Neutral, 5	Harness, Wiring, 5
Barrier, 6	Harness, Wiring – 3 Wire Start, 36
Barrier, Bar – Cross, 6	Harness, Wiring – Battery Charger, 26, 28, 30
Barrier, Base, 5	Harness, Wiring - Battery Charger Alarm, 24
Barrier, Chute - Arc, 6	Harness, Wiring - Elevator Signal, 31
Barrier, Handle, 4	Harness, Wiring – Main, 12
Barrier, Phase, 6	Harness, Wiring - Main (600 Volts), 14
Barrier, Retainer, 6	Harness, Wiring - Meter, 18
Barrier, Switch, 7	Harness, Wiring - Programmed Transition, 35
Base, Mounting, 5	Hinge, Door, 20
Block and Cross Bar Assembly, 5, 6	Holder, Fuse, 26, 28, 30
Block, Auxiliary, 14	Housing, Pin, 40
Block, Contact, 6, 18, 22	Housing, Socket, 40
	Insert, 6
Block, Terminal, 4, 12, 14	Jumper, Terminal, 4
Block, Terminal – Sectional, 21, 24, 31, 34, 36	Key, 18, 37
Board, PC – 2 to 3 Wire Convertor, 36	Label, Block - Terminal, 21, 31, 34, 36
Board, PC – Battery Charger, 26, 28, 30	Label, Operation, 22
Board, PC – Elevator Signal, 31	Label, Switch, 22
Board, PC – Mother, 10	Latch, Cam, 20
Board, PC – Programmed Transition, 35	Lever, Switch – Auxiliary, 7
Board, PC – Sequencer, 38	Light, Indicating, 18
Board, PC – Time Delay, 10	Lug, Solderless, 5 , 6
Board, PC - Transformer, 10	Marker, Adhesive – Relay, 22
Board, PC – Voltage Sensor, 10	Meter, Ampere, 20
Bracket, Accessory Control Plate, 12	Meter, Ampere – DC, 26 , 28 , 30
Bracket, Door, 20	Meter, Frequency, 18
Bracket, End, 23	Meter, Volt, 18
Bracket, End – Terminal, 21, 24, 31, 34, 36, 37	Module, Alarm, 33
Bracket, Plate - Door, 14	Mount, Tie - Cable, 26 , 28 , 30
Bracket, Switch - Auxiliary, 7	Paint, Green, 20
Bracket, Terminal, 4	Pin and Ribbon Assembly, 10, 31, 36
Breaker, Circuit, 4	Pin, Contact, 40
Bumper, 20	Pin, Hinge, 20
Cabinet, Control, 18	Plate, Clock – Exerciser, 32
Capacitor, 4	Plate, Door, 12 , 14
Chute, Arc, 6	Plate, End – Terminal, 21, 24, 31, 34, 36
Clamp, 5	Plate, Mounting – Sequencer, 38
Clip, Pin, 20	Plug, Hole, 10 , 18 , 20
Clock, Exerciser, 32	Plug, Keying, 10
Conduit - Transfer Switch to Generator Set, 44	Rail, Block – Terminal, 24
Contactors, Interlocking, 14	Rail, Relay, 37
Cover, Transition – Programmed, 35	Rail, Terminal, 21, 23, 31, 34, 36
Cover, Board – PC, 10	
Cover, Charger – Battery, 26, 28, 30	Rectifier, SCR 28, 30
Cover, Contact, 4	Rectifier, SCR, 28, 30
	Relay, 24VAC, 12 , 14
Cover Single Floretor 21	Relay, Control, 22, 23, 37
Cover, Signal – Elevator, 31	Relay, Programmed Transition, 35
Cover, Start – 3 Wire, 36	Resistor, Fixed, 26
Door, Cabinet, 20	Rod, Actuator, 4

Index

Rod-End, Actuator, 4

Sequencer, 38

Shield, Accessory Control Plate, 12, 14

Shield, Meter, 18

Sleeving, Insulation, 20

Socket, Contact, 40

Spacer, Bar - Neutral, 20

Spacer, Mounting, 6

Splice, Inline, 33

Spring, Conical, 20

Standoff, Insulator, 5

Strain Relief, 40

Strip, Marker, 4

Switch, 5

Switch Assembly, Auxiliary, 7

Switch, Action - Snap, 7

Switch, Auxiliary, 5

Switch, Selector, 18, 22, 37

Switch, Toggle, 12, 14

Switch, Transfer, 2, 4, 44

Switch, Voltmeter, 20

Tag, Terminal, 21, 31, 34, 36

Tape, Sealing - Transfer Switch to Generator Set, 44

Template, Module - Alarm, 33

Terminal, 5, 6

Terminal, Ring, 23

Terminal, Spade, 26, 28, 30

Terminal, Tap, 5

Terminal, Tap - Plier, 23

Tie, Cable, 4, 20, 22, 26, 28, 30, 31, 32, 35, 36

Transformer (Primary Voltage), 26, 28, 30

Transformer, Current, 20

Transformer, Power, 12, 14

Transformer, Stepdown, 20

Transition, Programmed, 35

U-Strap, 6

Washer, Centering, 26

Wrapper, Charger - Battery, 26, 28, 30

Feature/Options


Beginning with Spec J, feature option codes applicable to the individual unit are listed on the Transfer Switch Nameplate. The following describes these codes;

A028 A035 A036 A037 A038 A041 A042 A044 A045 A046 A047	Poles – 3 Application – Utility to Genset Application – Utility to Utility Application – Genset to Genset Application – Non–Automatic/Remote System – 1 Phase 2 or 3 Wire System – 3 Phase 3 or 4 Wire Frequency – 60 Hertz Frequency – 50 Hertz Listing – UL Certification – CSA	L004 L005 L101 L102 L103 L104 L201 L202 L203 L204	Auxiliary Relay – Emergency Source Auxiliary Relay – Normal Source Auxiliary Relay – 24 VDC Coil Auxiliary Relay – Emergency Position Auxiliary Relay – Normal Position Auxiliary Relay – Genset Start Auxiliary Relay – 12 VDC Coil Auxiliary Relay – Emergency Position Auxiliary Relay – Normal Position Auxiliary Relay – Genset Start
A048	Listing - Not Applicable	M001	Module – Signal
		M002	Module – 3 Wire Start
B001	Cabinet – Type 1	M003	Terminal Block - 30 Place
B002	Cabinet – Type 3R	M004	Monitor – Phase/Sequence Balance
B003	Cabinet – Type 4	M006	Sequencer – Standby Set Start 12 Volt
B004	Construction - Open	M007	Load Shed – From Emergency
		M008	Module - Alarm
C015 C016	Start Time Delay – 90 Seconds Control – Over Voltage & Over/Under	M010	Sequencer – Standby Set Start 24 Volt
	Hertz Source 2	N001	Switch - Auto/Manual
C017	Control – Over Voltage & Over/Under Hertz Source 1	N002	Terminal Block – Battery Charger Alarm
D001	Meters – None	N005	Terminal Block – Source 1/2 Remote Signal
D002	Meters – Door Mounted	N013	Harness, Extension – 4 Feet
J001	Clock - 7 Day Exerciser	R020	Voltage – 120
J021	Programmed Transition 0.5 to 7.5	R021	Voltage – 208
	Second Delay	R022	Voltage – 220
J022	Programmed Transition 1 to 60	R023	Voltage – 240
	Second Delay	R024	Voltage - 380
		R025	Voltage – 416
K001	Battery Charger - 2 Amp, 12/24 Volt	R026	Voltage – 480
K002	Battery Charger – 10 Amp, 12 Volt	R027	Voltage – 600
K003	Battery Charger - 10 Amp, 24 Volt		
		S046	Current Rating – 40 Amps
L001	Auxiliary Relay - 24 VAC Coil	S047	Current Rating – 70 Amps
L002 L003	Auxiliary Relay – Emergency Position Auxiliary Relay – Normal Position	S048	Current Rating – 125 Amps
	-		


Abbreviations

Some of the following abbreviations may be used throughout this Parts Catalog;

Alternating Current	AC
Ampere	Amp
As Required	A/R
Automatic Voltage Regulator	AVR
Direct Current	DC
External Tooth	ET
External-Internal Tooth	EIT
Inside Diameter	ID
Internal Tooth	IT
Kilowatt	kW
Liquid Petroleum Gas	LPG
Left	LT
Meter	M(meter number)
Millimeter	mm
Not for sale	NFS
Nominal Pipe Thread	NPT
Outside Diameter	OD
Phase	Ph
Printed Circuit	PC
Right	RT
Specification	Spec
Union National Coarse	UNC
Union National Fine	UNF
Volts Alternating Current	VAC
Volts Direct Current	VDC
With	W/(ET, IT, or EIT)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Switch Assembly - Transfer				50 Hertz
			(Includes parts marked *)		306-3486-03	1	220 Volt, 1 Ph, 2 Wire
			40 Amp 60 Hertz		306-3486-03	1	115/200 Volt, 1 Ph, 3 Wire
	206 2405 01	4	120 Volt, 1 Ph, 2 Wire		306-3486-03	1	220/380 Volt, 3 Ph, 4
	306 –3485–01 306 –3485–03		120/240 Volt, 1 Ph, 3		300-3400-03	'	Wire
			Wire		306-3486-03	1	120/208 Volt, 3 Ph, 4
	306-3 485-03	1	120/208 Volt, 3 Ph, 4				Wire
			Wire		306-3486-05	1 1	240/416 Volt, 3 Ph, 4
	306-3485-03	1	120/240 Volt, 3 Ph, 4				Wire
			Wire				125 Amp
	306-3485-06	1	240/480 Volt, 3 Ph, 4				60 Hertz
			Wire		306-3487-01	1	120 Volt, 1 Ph, 2 Wire
	306-3485-05	1	220/380 Volt, 3 Ph, 4		306-3487-03	1	120/240 Volt, 1 Ph, 3
			Wire				Wire
	306-3485-06	1	277/480 Volt, 3 Ph, 4		306-3487-03	1	120/208 Volt, 3 Ph, 4
			Wire				Wire
	306-3485-04	1	347/600 Volt, 3 Ph, 4		306-3487-03	. 1	120/240 Volt, 3 Ph, 4
			Wire				Wire
			50 Hertz		306-3487-06	1	240/480 Volt, 3 Ph, 4
	306-3485-03	1	220 Volt, 1 Ph, 2 Wire				Wire
	306-3485-03		115/200 Volt, 1 Ph, 3		306-3487-05	1	220/380 Volt, 3 Ph, 4
		•	Wire				Wire
	306-3485-03	. 1	220/380 Volt, 3 Ph, 4		306-3487-06	: 1	277/480 Volt, 3 Ph, 4
		•	Wire				Wire
	306-3485-03	. 1	120/208 Volt, 3 Ph, 4		306-3487-04	. 1	347/600 Volt, 3 Ph, 4
	000 0 100 00	•	Wire				Wire
	306-3485-05	1	240/416 Volt, 3 Ph, 4				50 Hertz
		•	Wire		306-3487-03	1	220 Volt, 1 Ph, 2 Wire
			70 Amp		306-3487-03		115/200 Volt, 1 Ph, 3
			60 Hertz			,	Wire
	306-3486-01	1	120 Volt, 1 Ph, 2 Wire		306-3487-03	: 1	220/380 Volt, 3 Ph, 4
	306-3486-03		120/240 Volt, 1 Ph, 3				Wire
	000 0 100 00	•	Wire		306-3487-03	1	120/208 Volt, 3 Ph, 4
	306-3486-03	. 1	120/208 Volt, 3 Ph, 4			•	Wire
	000 0400 00	•	Wire		306-3487-05	. 1	240/416 Volt, 3 Ph, 4
	306-3486-03	. 1	120/240 Volt, 3 Ph, 4		000 0101 00	•	Wire
	000-0400-00	,	Wire				******
	306-3486-06	: 1	240/480 Volt, 3 Ph, 4				
	300-3400-00	•	Wire				
	306-3486-05	: 1	220/380 Volt, 3 Ph, 4				
	300-3460-03	' '	Wire				
	306-3496-06	: 1	277/480 Volt, 3 Ph, 4				
	306-3486-06	' 1	Wire Voit, 3 Fii, 4				
	206 2406 04	1	347/600 Volt, 3 Ph, 4	Con	tinued on next	nage	
	306-3486-04	. 1		OUII	imueu on next	page	
			Wire				




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
· 1	306–3384	1	*Switch Assembly (See separ-				50 Hertz
·		•	ate page for components)		320-0606	1	220 Volt, 1 Ph, 2 Wire
2	306-3404	1	*Cover, Contact (Includes Label)		320-0606	1	115/200 Volt, 1 Ph, 3 Wire
_	098–5586	i	*Label		320-0606	i	220/380 Volt, 3 Ph, 4 Wire
3	332-2605	2	*Jumper, Terminal		320-0606	1	120/208 Volt, 3 Ph, 4 Wire
4	821-0005	4	*Screw, Lock - Flange		320-0876	1	240/416 Volt, 3 Ph, 4 Wire
•	02. 0000	•	(#10–32 x 1/2)	14	306–3395	i .	*Rod, Actuator
5			*Actuator, Linear	15	306–1989	2	*Barrier, Handle
•			60 Hertz	16	332–2832	2	*Block, Terminal
	306-3401-01	1	120 Volt, 1 Ph, 2 Wire	17	002 2002	_	*Capacitor
	306-3401-03		120/240 Volt, 1 Ph, 3 Wire				60 Hertz
	306-3401-03		120/208 Volt, 3 Ph, 4 Wire		312-0257-03	1	120 Volt, 1 Ph, 2 Wire
	306-3401-03		120/240 Volt, 3 Ph, 4 Wire		312-0203	1	120/240 Volt, 1 Ph, 3 Wire
	306-3401-06		240/480 Volt, 3 Ph, 4 Wire		312-0203	1	120/208 Volt, 3 Ph, 4 Wire
	306-3401-05		220/380 Volt, 3 Ph, 4 Wire		312-0203	1	120/240 Volt, 3 Ph, 4 Wire
	306-3401-06		277/480 Volt, 3 Ph, 4 Wire		312-0257-01		240/480 Volt, 3 Ph, 4 Wire
	306-3401-03		347/600 Volt, 3 Ph, 4 Wire		312-0228	2	220/380 Volt, 3 Ph, 4 Wire
			50 Hertz		312-0257-01	2	277/480 Volt, 3 Ph, 4 Wire
	306-3401-03	1	220 Volt, 1 Ph, 2 Wire		312-0257-02		347/600 Volt, 3 Ph, 4 Wire
	306-3401-03	1	115/200 Volt, 1 Ph, 3 Wire				50 Hertz
	306-3401-03		220/380 Volt, 3 Ph, 4 Wire		312-0203	1	220 Volt, 1 Ph, 2 Wire
	306-3401-03	1	120/208 Volt, 3 Ph, 4 Wire		312-0203	1	115/200 Volt, 1 Ph, 3 Wire
	306-3401-05	1	240/416 Volt, 3 Ph, 4 Wire		312-0203	1	220/380 Volt, 3 Ph, 4 Wire
6	815-0652	6	*Screw, Cap - Hex Head - W/IT		312-0203	1	120/208 Volt, 3 Ph, 4 Wire
			(#10-32 x 1/2)		312-0228	2	240/416 Volt, 3 Ph, 4 Wire
7	526-0008	5	*Washer, Flat (#10)	18	815-0029	4	*Screw, Machine - Flat Head
8	800-0008	2	*Screw, Cap - Hex Head				(#10-32 x 1/2)
			(1/4-20 x 1-1/4)	19	870-0131	4	*Nut, Hex – W/ET (#10–32)
9	850-0040	2	*Washer, Lock (1/4)	20	306-3394	1	*Bracket, Terminal
10	526-0018	2	*Washer, Flat (1/4)	21	332-0942	4	*Tie, Cable
11	815-0651	6	*Screw, Machine – Round Head	22	332-2903	2	*Strip, Marker
			(#6–32 x 3/4)		821-0028	4	Screw, Lock (3/8-16 x 1/2) (Not
12	306-3400-01	2	*Rod–End, Actuator				illustrated)
13			*Breaker, Circuit		8700133	4	Nut, Lock (3/8–16) (Not
			60 Hertz				illustrated)
	320-0608	1	120 Volt, 1 Ph, 2 Wire				
	320-0606	1	120/240 Volt, 1 Ph, 3 Wire				
	320-0606	1	120/208 Volt, 3 Ph, 4 Wire				
	320-0606	1	120/240 Volt, 3 Ph, 4 Wire				
	320-0876	1	240/480 Volt, 3 Ph, 4 Wire				
	320-0876	1	220/380 Volt, 3 Ph, 4 Wire				
	320–0876	1	277/480 Volt, 3 Ph, 4 Wire			_	
	320-0876	1	347/600 Volt, 3 Ph, 4 Wire	* Pa	rts included in 1	Fransfer S	Switch Assembly

Switch Assembly




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	306-3384		Switch Assembly (Includes parts	16	526-0008	2	*Washer, Flat (#10)
			marked *)	17	815–0180	3	*Screw, Cap – Hex Head
1	306-3399	1	*Base, Mounting				(#10-32 x 3/4)
2	306-3403	1	*Barrier, Base	18	306–3397	1	*Bar, Interlock
3	306–2013	1	*Block and Cross Bar Assembly	19	337–2315	1	*Bar, Bus – Load
			(See separate page for	20	332–2370	5	*Standoff, Insulator
			components)	21	800-0004	5	*Screw, Cap – Hex Head
4	815–0653	4	*Screw, Machine – Round Head				(1/4–20 x 5/8)
			(#10–32 x 1–3/4)	22	851-0027	6	*Washer, Conical (1/4)
5	306-4173	1	*Switch Assembly, Auxiliary –	23	337–2316	1	*Bar, Bus – Load
			Emergency (See separate	24			*Lug, Solderless
			page for components)		332–2880	6	Spec G
6	815-0652	9	*Screw, Machine – Hex Head		332-3084	6	Spec H & J
			W/IT (#10–32 x 1/2)	25	337–2313	1	*Bar, Bus – Load
7	332-2352	1	*Clamp	26	800–0005	1	*Screw, Cap Hex Head
8	3382012	1	*Harness, Wiring				(1/4–20 x 3/4)
9	821-0005	6	*Screw, Locking Head (#10–32 x	27	526–0018	6	*Washer, Flat (1/4)
			1/2)	28	850-0040	6	*Washer, Lock (1/4)
10	851-0031	9	*Washer, Conical (#10)	29	862-0001	1	*Nut, Hex (1/4–20)
11	337–2314	3	*Bar, Bus – Jumper	30	337-2317	1	*Bar, Neutral
12	332-2834	3	*Terminal, Tap	31	800-0003	5	*Screw, Cap – Hex Head
13	306-4172	1	*Switch Assembly, Auxiliary –				(1/4–20 x 1/2)
			Normal (See separate	32	8500030	3	*Washer, Lock (#10)
			page for components)	33	332-2366	1	*Terminal
14	306–2013	1	*Block and Cross Bar Assembly (See separate page for components)	34	870–0053	3	*Nut, Hex (#10–32)
15	815–0538	2	*Screw, Machine – Round Head W/IT (#8–32 x 1/2)	* Pa	rts included in	n 306–3384	4 Switch Assembly

Block and Cross Bar Assembly




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Block and Cross Bar Assembly	12	306-1962	1	*Barrier, Retainer
			(Includes parts marked *)	13	306-1964	1	*Barrier, Phase - Left Hand
	306-2013	1	Emergency	14	306-1965	1	*Barrier, Phase - Right Hand
	306-2017	1	Normal	15	815-0527	2	*Screw, Pan Head - Thread
1	306-2031	1	Block, Contact				Forming (#10-16 x 1/2)
2	306-1972	1	Bar, Cross	16	3061996	1	*Handle Assembly, Actuator
3	815–0539	2	Screw, Machine – Round Head W/IT (#8–32 x 5/8)				(See separate page for components)
4	306-1968	3	U-Strap	17	815-0388	2	*Screw, Pan Head - Cross
5	306-3495	3	Insert				Recessed (#6-32 x 1/2)
6			Lug, Solderless	18	850-0020	2	*Washer, Lock (#6)
	332-2835	3	Spec G	19	306-2032	1	*Barrier
	332-3085	3	Spec H & J	20	332-2366	3	*Terminal
7	813-0103	3	Screw, Machine - Round Head	21	526-0002	2	*Washer, Flat (#6)
			(#10-32 x 3/4)	22	526-0048	2	*Washer, Flat (#8)
8	306-1984	1	*Arm, Interlock	23	306-2178	1	*Spacer, Mounting
9	306-1961	3	*Chute, Arc				, , , ,
10	306- 1966	3	*Barrier, Chute – Arc				
11	306–1967	2	*Barrier, Bar - Cross	* Pa	rts included in	Block and	Cross Bar Assembly

Auxiliary Switch Assembly




REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
			Switch Assembly, Auxiliary (In	4	3090393	4	*Switch, Action – Snap
			cludes parts marked *)	5	815-0686	2	*Screw, Machine – Hex Head
	306-4174	1	Normal				(#6-32 x 3-1/4)
	306-4173	1	Emergency	6	870-0201	2	*Nut, Lock (#6-32)
1	306-4163	1	*Bracket, Switch - Auxiliary				
2	306-1993	1	*Lever, Switch - Auxiliary				
3	306-3391	5	*Barrier, Switch	* Pa	rts included in	n Auxiliary	Switch Assembly

Actuator Handle Assembly



REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	306–1996	1	Handle Assembly, Actuator (In cludes parts marked *)	4	812-0068	1	*Screw, Machine - Round Head (#6-32 x 1)
1	306-1994	1	*Handle, Switch - Left Hand	5	870-0201	2	*Nut, Lock (#6-32)
2	306-1995	1	*Handle, Switch - Right Hand				, ,
3	812-0066	1	*Screw, Machine – Round Head (#6–32 x 3/4)	* Pa	rts included in	306-1996	S Actuator Handle Assembly


Control Assembly



Control Assembly

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Board, Printed Circuit - Mother	5			Board, Printed Circuit - Trans-
	300-3090	1	Utility to Generator				former
	300-3267	1	Generator to Generator			•	60 Hertz
2			Cover, Board - Printed Circuit		300-3119	1	120 Volt, 1 Ph, 2 Wire
			(Includes Label)		300-3092	1	120/240 Volt, 1 Ph, 3 Wire
	3063470	1	Spec G & H		300-3092	1	120/208 Volt, 3 Ph, 4 Wire
	306-3980	1	Spec J		300-3092	1	120/240 Volt, 3 Ph, 4 Wire
3			Board, Printed Circuit - Time		300-3092	1	240/480 Volt, 3 Ph, 4 Wire
			Delay (J2)		300-3092	1	220/380 Volt, 3 Ph, 4 Wire
	300-3094	1	Standard		300-3092	1	277/480 Volt, 3 Ph, 4 Wire
	300-3261	1	Extended (90 sec.)		300-3118	1	347/600 Volt, 3 Ph, 4 Wire
4			Board, Printed Circuit - Voltage				50 Hertz
			Sensor (J1, J3)		300-3092	1	220 Volt, 1 Ph, 2 Wire
	300–3121	1	Undervoltage (50 & 60 Hz.)		300-3092	1	115/200 Volt, 1 Ph, 3 Wire
	300-3093-01	1	Over/Under Voltage & Over/		300-3092	1	220/380 Volt, 3 Ph, 4 Wire
			Under Frequency (60Hz)		300-3092	1	120/208 Volt, 3 Ph, 4 Wire
	300-3093-02	1	Over/Under Voltage & Over/		300-3092	1	240/416 Volt, 3 Ph, 4 Wire
			Under Frequency (50Hz)	6	815-0544	9	Screw, Machine - Round Head
	300-4275	1	Undervoltage (5 sec.)				W/IT (#6-32 x 1/2)
	300-4276-01	1	Overvoltage (5 sec.) (60 Hz.)	7	517-0256	10	Plug, Hole
	300-4276-02	1	Overvoltage (5 sec.) (50 Hz.)	8	323-1387	1	Pin and Ribbon Assembly
			, , ,	9	332-1877	5	Tie, Cable
				11	332-1917	3	Plug, Keying


Accessory Control Plate (All except 600 Volt)



Accessory Control Plate (All except 600 Volt)

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Plate, Door	7			Transformer, Power (T1, T2)
	301–9754	1	Standard				60 Hertz
	319-0002	1	Load Shed		315-0655-0	1 1	120 Volt, 1 Ph, 2 Wire
			Label		315-0655-02		120/240 Volt, 1 Ph, 3 Wire
	098–5773	1	Standard		315-0655-02		120/208 Volt, 3 Ph, 4 Wire
_	098–5680	1	_ Load Shed		315-0655-02		120/240 Volt, 3 Ph, 4 Wire
2	301–9774	1	Bracket (Includes Label)		315-0655-02		240/480 Volt, 3 Ph, 4 Wire
_	098–5681	1	Label, Bracket		315-0655-03		220/380 Volt, 3 Ph, 4 Wire
3	332–2884	1	Block, Terminal		315-0655-02		277/480 Volt, 3 Ph, 4 Wire
4		_	#*Relay, 3PDT - 24VAC		315-0655-03	3 1	347 Volt, 3 Ph, 4 Wire
	307-2575	2	Standard (K1, K2)		0.15 0055 01		50 Hertz
	307–2575	1	Load Shed from Emergency		315-0655-02		220 Volt, 1 Ph, 2 Wire
_	000 0400	4	(K1)		315-0655-02		115/200 Volt, 1 Ph, 3 Wire
5 6	308– 0406	1	Switch, Toggle – DPDT (S1)		315-0655-00		220/380 Volt, 3 Ph, 4 Wire
O			*Harness, Wiring – Main Standard		315-0655-02		120/208 Volt, 3 Ph, 4 Wire
			60 Hertz	8	315065503 8210040	8	240/416 Volt, 3 Ph, 4 Wire
	338-2071	1	120 Volt, 1 Ph, 2 Wire	0	021-0040	0	Screw, Self-Locking - Flanged (#10-32 x 5/16)
	338-2062	1	120/240 Volt, 1 Ph, 3 Wire	9	810-0085	1	Screw, Machine – Round Head
	338-2062	1	120/208 Volt, 13 H, 3 Wire	9	010-0000	ı	Brass (#8–32 x 1–1/8)
	338-2062	1	120/240 Volt, 3 Ph, 4 Wire	10	815-0539	2	Screw, Machine – Round Head
	338–2062	1	240/480 Volt, 3 Ph, 4 Wire	10	010-0000	_	W/IT (#8–32 x 5/8)
	338-2062	i	220/380 Volt, 3 Ph, 4 Wire	11	860-0008	1	Nut, Hex (#8–32)
	338–2062	1	277/480 Volt, 3 Ph, 4 Wire	12		4/R	Screw, Pan Head W/ET
	338–2062	1	347 Volt, 3 Ph, 4 Wire		0.0 0000 /	V	(#6–32 x 3/8)
			50 Hertz	13	526-0048	1	Washer, Flat (#8)
	338-2062	1	220 Volt, 1 Ph, 2 Wire	14	307-2648	2	#Relay, 4 Pole - 24VAC (Only
•	338-2062	1	115/200 Volt, 1 Ph, 3 Wire				used on Load Shed from Emer-
	338-2062	1	220/380 Volt, 3 Ph, 4 Wire				gency Units) (K2, K4)
	338-2062	1	120/208 Volt, 3 Ph, 4 Wire	15	870-0221	1	Nut, Lock W/ET (#8-32)
	338-2062	1	240/416 Volt, 3 Ph, 4 Wire	16	856-0002	1	Washer, Lock E/EIT (#8)
			Load Shed from Emergency	17	098-5387	4	Label, Danger
			60 Hertz	18	870-0131	6	Nut, Lock W/ET (#10-32)
	338–2096	1 .	120 Volt, 1 Ph, 2 Wire	19	301-9961	1 .	Shield (Includes Label)
	338–2097	1	120/240 Volt, 1 Ph, 3 Wire		098–5699	1	Label
	338–2097	1	120/208 Volt, 3 Ph, 4 Wire	20	815–0544	8	Screw, Machine - Round Head
	338–2097	1	120/240 Volt, 3 Ph, 4 Wire				W/IT (#6-32 x 1/2)
	338–2097	1	240/480 Volt, 3 Ph, 4 Wire	21	098–5589	1	Label, Caution
	338–2097	1	220/380 Volt, 3 Ph, 4 Wire				
	338-2097	1	277/480 Volt, 3 Ph, 4 Wire				
	338-2097	1	347 Volt, 3 Ph, 4 Wire				
	000 0007		50 Hertz				
	338-2097	1	220 Volt, 1 Ph, 2 Wire				
	338–2097	1	115/200 Volt, 1 Ph, 3 Wire				
	338-2097	1	220/380 Volt, 3 Ph, 4 Wire	* Lo	ad Shed Units	use Refer	ence #14
	338–2097 338–2097	1	120/208 Volt, 3 Ph, 4 Wire 240/416 Volt, 3 Ph, 4 Wire	# No	te: If custome	er request	s K2 Relay, if K4 filled, supply
	338-2337	1	Non-Automatic (120 Volt				pply 307–2575
	550 – 2557	ı	Only)				

Accessory Control Plate (600 Volt)



Accessory Control Plate (600 Volts)

REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
	110.	OOLD	DESCRIPTION	110.	140.	OOLD	DEGOME HON
1	3190009	1	Plate, Door (Includes Label)	11	860-0008	1	Nut, Hex (#8-32)
	098–5734	1	Label	12	815-0550	6	Screw, Pan Head Cross Re-
2	301–977 4	1	Bracket (Includes Label)				cessed W/ET (#6-32 x 3/8)
	098-5681	1	Label	13	526-0048	1	Washer, Flat (#8)
3	332-2884	1	Block, Terminal	14	307-2648	1	Relay, 4 Pole – 24VAC (Load
4	307-2597	1	Contactors, Interlocking				Shed from Emergency Units)
			(24VAC)	15	870-0221	1	Nut, Lock W/ET (#8–32)
5	308–0406	1	Switch, Toggle (S1)	16	856-0002	1	Washer, Lock W/EIT (#8)
6			*Harness, Wiring – Main (600	17	098–5387	4	Label, Danger
			Volts)	18	870–0131	6	Nut, Lock W/ET (#10–32)
	338–2072	1	Standard	19	301-9961	1	Shield (Includes Label)
	338–2098	1	Load Shed from Emergency		098–5699	1	Label
_	338– 2337	1	Non-Automatic	20	815–0544	8	Screw, Machine - Round Head
7		_	Transformer, Power (T1, T2)				W/IT (#6-32 x 1/2)
	315-0655-04		Spec G	21	098–5589	1	Label, Caution
_	315–0662	2	Spec H & J	22	307–2600–01	1	Block, Auxiliary
8	821–0040	8	Screw, Self-Locking - Flanged (#10-32 x 5/16)				
9	810-0085	1	Screw, Machine – Round Head (#8–32 x 1–1/8)				
10	815–0538	2	Screw, Machine – Round Head Cross Recessed W/IT (#8–32 x 5/8)	* Loa	ad Shed Units ເ	use Refere	ence #14
			,				

^{*} Load Shed Units use Reference #14

Plate Assembly (Open Construction)





Plate Assembly (Open Construction)

REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	301-9961	1	Shield (Includes Silkscreen)	19	319-2050-01	1	Plate, Open Construction
2	098-5387	2	Label, Danger	20	322-0133	4	Lamp, Indicating
3	322-0392-06	1	Housing, Lamp (White)	21			Harness, Wiring - Main (Not
4	322-0392-04	1	Housing, Lamp (Green)				Shown)
5	322-0392-02	1	Housing, Lamp (Amber)				Non-Automatic/Remote
6	322-0392-01	1	Housing, Lamp (Red)		338-2958	1	All Except 600 Volt
7	815-0538	8	Screw, Machine - Round Head		338-2957	1	600 Volt
			Cross Recessed w/IT				Load Shed
			(#8-32 x 1/2)		338-2959	1	120 Volt
8	815-0544	22	Screw, Machine - Round Head		338-2982	1	600 Volt
			Cross Recessed w/IT		338-2981	1	All Except 120 & 600 Volt
			(#6-32 x 1/2)				All Except Non-Automatic/
9	332-2837-07	1	Rail, Terminal				Remote & Load Shed
10	332-2839	2	Bracket, End - Terminal		338-2961	1	120 Volt
11	332-2842-16	2	Tag, Terminal (51-60)		338-2960	1	600 Volt
12	332-2836-02	1	Block, Terminal - Sectional		338-2962	1	All Except 120 & 600
13	332-2841	1	Plate, End – Terminal				Volt
14	815-0446	4	Screw, Round Head - Cross	22			Transformer, Power
			Recessed w/IT Thread Cutting		315-0723-05	2	120 Volt
			(#8–32 x 1/2)		315072306	2	208/220/240/480 Volt
15	332-2877	2	Tie, Cable		315-0723-07	2	380/416 Volt
16	870-0131	4	Nut, Hex w/ET (#10-32)		315-0723-08	2	600 Volt
17	878-0032	1	Laminate Material		315-0662	2	600 Volt
18	098–5710	1	Label, Block – Terminal				




Door and Cabinet

REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Cabinet, Control	14			Meter, Volt – AC
			Spec G				60 Hertz
	301–9766	1	NEMA 1		302-1692	1	120 Volt, 1 Ph, 2 Wire
	319-0363	1	NEMA 3R		302-1175	1	120/240 Volt, 1 Ph, 3 Wire
	319–0152	1	NEMA 4		302-1175	1	120/208 Volt, 3 Ph, 4 Wire
			Spec H & J		302-1175	1	120/240 Volt, 3 Ph, 4 Wire
	3191182	1	NEMA 1		302-1711	1	240/480 Volt, 3 Ph, 4 Wire
	319–0363	1	NEMA 3R		302-1711	1	220/380 Volt, 3 Ph, 4 Wire
	319-0152	1	NEMA 4		302-1711	1	277/480 Volt, 3 Ph, 4 Wire
	319-0363-01	1	NEMA 12		302-1710	1	347/600 Volt, 3 Ph, 4 Wire
2	322-0170	1	Light, Indicating – Normal				50 Hertz
			(Green)		302-1175	1	220 Volt, 1 Ph, 2 Wire
3	322-0137	1	Light, Indicating – Emergency		302-1175	1	115/200 Volt, 1 Ph, 3 Wire
			(Red)		302-1711	1	220/380 Volt, 3 Ph, 4 Wire
4	322-0387-02	1	Light, Indicating – Normal		302-1175	1	120/208 Volt, 3 Ph, 4 Wire
			Source Available (Clear)		302-1711	1	240/416 Volt, 3 Ph, 4 Wire
5	322-0168	1	Light, Indicating – Emergency	15			Harness, Wiring – Meter
			Source Available (Amber)				60 Hertz
6			Switch, Selector (Includes Key) (S12)		338–2063	1	120 Volt, 1 Ph, 2 Wire (P12/TB4/S13/M2,3,4)
	308-0848	1	Spec G		338-2135	1	120 Volt, 1 Ph, 2 Wire
	308-0849	1	Key (fits Item 6, Spec G)				(P12/TB4/S13/M2,3,4)
			Spec H & J				(250 – 1000 Amp Meter)
			NEMA 1		338-2133	1	120/240 Volt, 1 Ph, 3 Wire
	308-0991	1	Utility to Utility				(P12-1/TB4/S13/M2,3,4)
	308-0992	1	Non-Automatic/Remote		338-2133	1	120/208 Volt, 3 Ph, 4 Wire
	308-0997	1	Sequencer – Standby				(P12-1/TB4/S13/M2,3,4)
			Set Start		338-2133	1	120/240 Volt, 3 Ph, 4 Wire
			NEMA 4				(P12-1/TB4/S13/M2,3,4)
	308-0993	1	Non-Automatic/Remote		338-2134	1	240/480 Volt, 3 Ph, 4 Wire
	308-0994	1	Utility to Genset				(P12/TB4/T3/S13/M2,3,4)
	308-1054	1	Fire Pump Applications		338-2134	1	220/380 Volt, 3 Ph, 4 Wire
	308-1055	1	Fire Pump Applications				(P12/TB4/T3/S13/M2,3,4)
	308-0989	1	Key (Fits item 6,		338-2134	1	277/480 Volt, 3 Ph, 4 Wire
			Spec H & J)				(P12/TB4/T3/S13/M2,3,4)
7	308-0854	1	Block, Contact - Normally		338-2134	1	347/600 Volt, 3 Ph, 4 Wire
			Closed (1 Phase)				50 Hertz
8	308-0850	1	Block, Contact - Normally Open		338-2133	1	220 Volt, 1 Ph, 2 Wire
			(1 Phase)				(P12-1/TB4/S13/M2,3,4)
9	406-0613	1	Handle, Door (Includes Key)		338-2133	1	115/200 Volt, 1 Ph, 3 Wire
	406-0649	1	Key (Fits item 9)				(P12-1/TB4/S13/M2,3,4)
10	517-0137	2	Plug, Hole		338-2134	1	220/380 Volt, 3 Ph, 4 Wire
11	302-1992	1	Meter, Frequency (45 – 65 Hz)				(P12/TB4/T3/S13/M2,3,4)
12	306-3464	1	Shield, Meter		338-2133	1	120/208 Volt, 3 Ph, 4 Wire
13	870-0439	6	Nut, Nylon				(P12-1/TB4/S13/M2,3,4)
.0	_, , _ ,	-	· · · · · · · · · · · · · · · · · · ·		338–2134	1	240/416 Volt, 3 Ph, 4 Wire (P12/TB4/T3/S13/M2,3,4)
					338-3203	1	Open Construction

Continued on next page


Door and Cabinet (Continued)



Door and Cabinet (Continued)


REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
16	302–1805–01	1	Meter, Ampere 40 Amp	29	815–0544	14	Screw, Machine – Round Head (#6-32 x 1/2)
	302-1678	1	70 Amp	30	332-2877	7	Tie, Cable
	302-1805-02	-	125 Amp	31	332-1348	2	Spacer, Bar – Neutral
17		•	Transformer, Current	32	319-0145	1	Cover, Meter
• • •			1 Phase	33	319-0146	1	Gasket, Cover – Meter
	338-2204-01	1	40 Amp	34	517-0266	A/R	Plug, Hole
	338-2204-02		70 Amp	35	812-0177	8	Screw, Machine – Round Head
	338-2204-03		125 Amp		0.12 0.77	ŭ	(5/16–18 x 3/4)
			3 Phase	36	406-0519	8	Spring, Conical
	338-2205-01	1	40 Amp	37	301-6727	8	Bracket, Door
	338-2205-02		70 Amp	38	525-0305	1	Paint, Green – 13 oz. Spray Can
	338-2205-03		125 Amp		098-5589	1	*Label, Caution
18			Door, Cabinet		815-0652	8	*Screw, Hex Head – Thread
			Spec G			-	Forming (#10–32 x 1/2)
			NEMA 1		870-0281	A/R	*Nut, Lock (3/8–16)
	301-9806	1	With Meter Holes		323-1333	1	*Connector
	301-9760	1	Without Meter Holes		098-5692	1	*Label, Product ID
			NEMA 3R		098-5693	1	*Label, Lamp
	319-0362-02	1	With Meter Holes				*Label, Door
	319-0362-01	1	Without Meter Holes		098-5694	1	With Switch
			NEMA 4		098-5695	1	Without Switch
	319-0143-02		With Meter Holes		098-5387	3	*Label, Danger
	319-0143-01	1	Without Meter Holes		870-0131	11	*Nut, Hex (#10-32)
			Spec H & J		870-0134	6	*Nut, Lock (1/4–20)
			NEMA 1		098-5589	1	*Label, Caution
	319-1176-01		With Meter Holes		518-0404	1	*Adhesive
	319-1178-01	1	Without Meter Holes		508-0233	A/R	*Washer, Rubber
			NEMA 3R		870–0386	16	*Nut, Acorn (Nylon)
	319-0362-04		With Meter Holes				*Gasket, Door
	319-0362-03	1	Without Meter Holes		895–0293–		22.57" Long
			NEMA 4		895–0293–		23.82" Long
	319-0143-04		With Meter Holes		895-0293-		26.13" Long
	319-0143-03	1	Without Meter Holes		895-0293-		26.70" Long
	040 0000 05		NEMA 12		895-0293-		28.39" Long
	319-0362-05		With Meter Holes		895-0293-		28.68" Long
	319-0362-06		Without Meter Holes		895-0293-		32.38" Long
10	319–0124	1	Open Construction		895-0293-		34.73" Long
19	306-3465	1	Latch, Cam		895–0293– 895–0293–		38.14" Long
	306-3466	1	NEMA 1 – Single Point NEMA 1 – 3 Point				51.08" Long
	306–3525	1	NEMA 1 – 3 FOIR		895-0293- 098-5777-		65.24" Long *Label, Warning
20	406-0610-02		Hinge, Door		098–6635	1	*Label, Ground
21	406-0610-02		Pin, Hinge		870-0439	6	*Nut, Acorn
22	406-0610-04		Clip, Pin		526-0022	8	*Washer, Flat (5/16)
23	508-0231	3	Bumper		821-0028	2	*Screw, Lock (3/8–16 x 1/2)
24	000 0201	U	Switch, Voltmeter		815-0221	4	*Screw, Drive
~ ¬	308-0905	1	1 Phase		098–6367	1	Label, Torque
	308-0904	i	3 Phase		030 0007	•	Laber, Torque
25	898-0778	1	Sleeving, Insulation				
26	220 0170	•	Transformer, Stepdown (T3)				
	315-0731	1	380/416 Volt				
	315–0377	i	480/600 Volt				
27	821-0004	4	Screw, Lock (#10-32 x .31)				
28	508-1045	2	Edging	* – F	arts not Illus	strated	

Load Shed




REF	PART	QTY	PART	REF	PART	QTY	PART
NO.	NO.	USED	DESCRIPTION	NO.	NO.	USED	DESCRIPTION
1 2 3 4 5	332-2837-09 332-2836-01 332-2839 332-2841 332-2842-13	2 2 1	*Rail, Terminal Block, Terminal – Sectional Bracket, End – Terminal Plate, End – Terminal Tag, Terminal (21–30)	6 7 * No	870–0221 098–5710 It used with Op	2 1 pen Constr	*Nut, Hex w/ET (#8–32) *Label, Block – Terminal ruction

Auto/Manual Switch




N.
14)
,
d – Cross
3-32 x 1/2)
Relay
,
y Only (Not
, only (Not

Auxiliary Relay




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	332-2879-02	1	Rail, Terminal	5	853-0005	2	Washer, Lock ET (#8)
2			Relay, Control	6	5260003	2	Washer, Flat (#8)
	307-2578	1	24 VAC	7	332-2230	1	Terminal, Tap - Plier
	307-2582	1	12 VDC	8	332-0802	1	Terminal, Ring (#8)
	307-2583	1	24 VDC		334-1842	1	Wire, 16 AWG - 600V TEW (12")
3	332-2878	2	Bracket, End				(Not Shown)
4	860-0008	2	Nut, Hex (#8-32)				•

Battery Charger Alarm




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	338-2349	1	Harness, Wiring Battery	5	332-2839	2	Bracket, End – Terminal
			Charger Alarm	6	332-2841	1	Plate, End – Terminal
2			Tie, Cable	7	332-2842-15	2	Tag, Terminal (41-50)
	332-0942	20	Units with Cabinets	8	8700221	2	Nut, Hex w/ET (#8-32) (Units
	332-0941	5	Open Construction				with Cabinets Only)
3	332-2837-0	9 1	Rail, Block – Terminal (Units with Cabinets Only)	9	098–5710	1	Label, Block – Terminal (TB3) (Units with Cabinets Only)
4	332-2836-0	12 1	Block, Terminal - Sectional				(




Battery Charger (2 Amp)

REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Harness, Wiring - Battery	14	304-0037	1	Resistor, Fixed – 6" Long
			Charger	15	304-0139	1	Resistor, Fixed – 2" Long
	338-2161	1	Units with Cabinet	16	304-0015	4	Washer, Centering
			Open Construction	17	813-0116	1	Screw, Round Head
	338–2949	1	Genset to Genset				(#10-32 x 6-1/2)
	338–2161	1	Utility to Genset	18	813-0112	1	Screw, Round Head
	338–2983	1	3 Wire Start				(#10-32 x 2-1/2)
2	870-0131	4	Nut, Lock W/ET (#1032)	19	870-0131	2	Nut, Lock W/ET (#10-32)
3	332–2777	2	Terminal, Spade	20	815-0550	4	Screw, Pan Head W/ET
4	332–2420	8	Mount, Tie – Cable				(#6-32 x 3/8)
5	332–0942	20	Tie, Cable	21	815–0549	4	Screw, Pan Head W/ET
6	301–9990	1	Wrapper, Charger – Battery				(#6–32 x 1/4)
7	301–9992	1	Cover, Charger – Battery (Includes Label)	22	821–0040	4	Screw, Lock (#10-32 x 5/16)
	098–5708	1	Label				
8	302-0807	1	Meter, Ampere – DC				
9	338–2149	1	Harness, Wiring – Battery				
			Charger				
10	321–0175	1	Holder, Fuse				
11	321-0153	1	Fuse, 3 Amp				
12	300–2946	1	Board, Printed Circuit – Battery Charger				
13			Transformer (Primary Voltage)				
			60 Hertz				
	315-0621-0		120 Volt				
	315-0621-0		208 Volt				
	315-0621-0		240 Volt				
	315-0621-0		380 Volt				
	315-0621-0		480 Volt				
	3150621-0	04 1	600 Volt				
			50 Hertz				
	315-0621-0		200 Volt				
	315-0621-0	-	208 Volt				
	315-0621-0		220 Volt				
	315-0621-0		380 Volt				
	315-0621-0	13 1	416 Volt				



Battery Charger (10 Amp 12 Volt)


REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1 2	098–4339	1	Label, Option Harness, Wiring – Battery Charger	14 15	321–0127	1	Fuse, 15 Amp Transformer (Primary Voltage) 60 Hertz
	338-2161	1	Units with Cabinet		315-0665	1	120 Volt
			Open Construction		3150665	1	208 Volt
	338-2949	1	Genset to Genset		315-0665	1	240 Volt
	338-2161	1	Utility to Genset		315-0671	1	380 Volt
	338-2983	1	3 Wire Start		315-0673	1	480 Volt
3	870-0131	4	Nut, Lock W/ET (#10-32)		315-0675	1	600 Volt
4	332-2777	2	Terminal, Spade				50 Hertz
5	332-2420	8	Mount, Tie - Cable		315-0667	1	200 Volt
6	332-0942	20	Tie, Cable		315-0669	1	220 Volt
7	319-0072	1	Wrapper, Charger - Battery		315-0677	1	240 Volt
8	319-0073	1	Cover, Charger - Battery		315-0679	1	347 Volt
			Label		315-0667	1	380 Volt
			500 Volt		315-0667	1	400 Volt
	098-5807	1	4.5 Amp		315-0669	1	416 Volt
	098-5808	1	2.5 Amp		315-0669	1	440 Volt
	098-5809	1	2.0 Amp	16	300-3160	1	Board, Printed Circuit - Battery
	098-5995	1	1.5 Amp				Charger
	0985996	1	1.0 Amp	17	305-0653	1	Rectifier, Bridge
			600 Volt	18	821-0040	4	Screw, Lock (#10-32 x 5/16)
	098-6039	1	1.0 Amp	19	815-0550	8	Screw, Pan Head W/ET
9	302-1844	1	Meter, Ampere – DC				(#6-32 x 3/8)
10	338-2223	1	Harness, Wiring – Battery	20	822-2048	5	Screw, Pan Head (#8-32 x 1/2)
			Charger	21	305-0781	1	Rectifier, SCR
11	321-0237	2	Holder, Fuse (AC Input)	22	822-2049	1	Screw, Pan Head W/ET
12	321-0104	1	Holder, Fuse (DC Output)				(#8-32 x 5/8)
13			Fuse	23	870-0221	5	Nut, Lock W/ET (#8-32)
			500 Volt	24	C-0308	1	Instruction Sheet
	321-0304-0	1 2	1.0 Amp				
	321-0304-0	2 2	1.5 Amp				
	321-0304-0	3 2	2.0 Amp				
	321-0304-0	4 2	2.5 Amp				
	321-0304-0	5 2	4.5 Amp				
			600 Volt				
	321-0236	2	1.0 Amp				



Battery Charger (10 Amp 24 Volt)


REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	098-4339	1	Label, Option	14	321-0127	1	Fuse, 15 Amp
2			Harness, Wiring – Battery	15			Transformer (Primary Voltage)
			Charger				60 Hertz
	338–2161	1	Units with Cabinet		3150701	1	120 Volt
			Open Construction		315-0701	1	208 Volt
	338–2949	1	Genset to Genset		315–0701	1	240 Volt
	338–2161	1	Utility to Genset		315-0707	1	380 Volt
	338-2983	1	3 Wire Start		315-0709	1	480 Volt
3	870-0131	4	Nut, Lock W/ET (#10–32)		315–0711	1	600 Volt
4	332–2777	2	Terminal, Spade				50 Hertz
5	332–2420	8	Mount, Tie – Cable		315-0703	1	200 Volt
6	332-0942	20	Tie, Cable		3150705	1	220 Volt
7	319–0072	1 .	Wrapper, Charger – Battery		315-0713	1	240 Volt
8	319–0073	1	Cover, Charger – Battery		315-0715	1	347 Volt
			Label		3150703	1	380 Volt
	098–5914	1	5.0 Amp		315-0703	1	400 Volt
	098– 5915	1	4.5 Amp		315–0705	1	416 Volt
	098–5916	1	2.5 Amp		3150705	1	440 Volt
	098–5997	1	2.0 Amp	16	300-3244	1	Board, Printed Circuit - Battery
	098–5998	1	1.5 Amp				Charger
9	302–1844	1	Meter, Ampere – DC	17	305-0653	1	Rectifier, Bridge
10	338-2223	1	Harness, Wiring Battery	18	821-0040	4	Screw, Lock (#10-32 x 5/16)
			Charger	19	815–0550	8	Screw, Pan Head W/ET
11	321–0237	2	Holder, Fuse (AC Input)				(#6-32 x 3/8)
12	321-0104	1	Holder, Fuse (DC Output)	20	822-2048	5	Screw, Pan Head (#8-32 x 1/2)
13			Fuse	21	3050781	1	Rectifier, SCR
	321-0304-0		1.5 Amp	22	822-2049	1	Screw, Pan Head W/ET
	321-0304-0		2.0 Amp				(#832 x 5/8)
	321-0304-0		2.5 Amp	23	870-0221	5	Nut, Lock W/ET (#8-32)
	321-0304-0		4.5 Amp	24	C-0308	1	Instruction Sheet
	321-0304-0	06 2	5.0 Amp				

Elevator Signal




REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	300–3096	1	Board, Printed Circuit – Elevator Signal (Includes Fuses)	7 8	332–2841	1	Plate, End – Terminal Tag, Terminal
	321-0174	5	Fuse, 5 Amp 250 Volt (F1-F5)		332-2842-12	2	Spec G (11–20)
2	301-9932	1	Cover, Signal - Elevator		332-2842-13	2	Spec H & J (21-30)
			(Includes Label)	9	815-0680	4	Screw, Pan Head Recessed
3			Harness, Wiring – Elevator				W/ET (#6-32 x 1)
			Signal	10	870-0221	2	Nut, Lock W/ET (#8–32)
	338-2141	1	Špec G	11	323-1409	1	Pin and Ribbon Assembly
	338-2140	1	Spec H & J	12	332-0942	10	Tie, Cable
4	332-2837-09	1	Rail, Terminal	13	098–5710	1	Label, Block - Terminal
5	332-2836-02	2	Block, Terminal – Sectional		332-2842-13	2	Tag, Terminal (21-30)
6	332–2839	2	Bracket, End - Terminal				(Not Illustrated)

Exerciser Clock




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1 2	301–9768 307–2577	1	Plate, Clock – Exerciser Clock, Exerciser	4	8150550	2	Screw, Machine – Round Head Cross Recessed W/ET
3	332-0942	10	Tie, Cable	5	8700131	2	(#6-32 x 3/8) Nut, Lock W/ET (#10-32)

Alarm Module




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Module, Alarm	4	862-0001	2	Nut, Hex (1/4-20)
	300-3998-01	1	24 Volt AC or DC	5	332-2230	2	Splice, Inline (22–18 Wire)
	300-3998-02	! 1	12 VDC	6	332-0942	3	Tie, Cable
2	800-0006	2	Screw, Cap – Hex Head (1/4–20 x 7/8)		539–1344	1	Template, Module – Alarm (Not Illustrated)
2	850_0040	2	Washer Lock (1/4)				•

Remote Connection Signal




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	332-2837-09) 1	Rail, Terminal	6	870-0221	2	Nut, Hex w/ET (#8-32)
2	332-2836-01	2	Block, Terminal - Sectional	7	332-0942	10	Tie, Cable
3	332-2839	2	Bracket, End - Terminal	8	098-5710	1	Label, Block - Terminal
4	332-2841	1	Plate, End - Terminal	9	332-2230	2	Terminal, Tap - Plier
5	332-2842-16	2	Tag. Terminal (51–60)				, ,

Programmed Transition




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Board, Printed Circuit – Programmed Transition	4	307–2591	. 1	Relay, Programmed Transition (K3)
	300-3115-01	1	07.5 Seconds	5	815-0680	4	Screw, Machine – Pan Head
	300-3115-02	! 1	60.0 Seconds				Cross Recessed W/ET
2			Cover, Programmed Transition				(#6–32 x 1)
			(Includes Silkscreen)	6	332-0942	8	Tie, Cable
	301-9928-01	1	07.5 Seconds	7	815-0550	2	Screw, Pan Head - Recessed
	301-9928-02	2 1	60 Seconds				W/ET (#6-32 x 3/8)
3	338–2139	1	Harness, Wiring – Pro grammed Transition				

2 to 3 Wire Convertor




REF NO.		QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Board, Printed Circuit - 2 to 3	8	332-2842-11		Tag, Terminal (1–10)
	300–3095	1	Wire Convertor Spec G & H	9	815–0680	4	Screw, Pan Head – Recessed W/ET (#6–32 x 1)
	300-4054	1	Spec J	10	8700221	2	Nut, Lock W/ET (#8-32)
2	319-1502	1	Cover, Start - 3 Wire (Includes	11	323-1408	1	Pin and Ribbon Assembly
			Label)	12	332-0942	12	Tie, Cable
3			Harness, Wiring - 3 Wire Start	13	098–5710	1	Label, Block – Terminal
	338-2142	1	Units with Cabinet	14	338-2993	1	Harness, Wiring (Open
	338-2987	1	Open Construction				Construction – Utility to Genset
4	332-2837-09	1	Rail, Terminal				Only)
5	332-2836-02	1	Block, Terminal - Sectional	15	332-2842-14	2	Tag, Terminal (31-40) (Open
6	332-2839	2	Bracket, End - Terminal				Construction Utility to Genset
7	332–2841	1	Plate, End – Terminal		¥		Only)

Remote Retransfer




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	332-2879-02	1	Rail, Relay	7	332-2230	2	Terminal, Tap - Plier
2	307-2578	2	Relay, Control	8 .	332-0802	2	Terminal, Ring (#8)
3	332-2878	2	Bracket, End - Terminal	9	308-0957	1	Switch, Selector (S12)
4	860-0008	2	Nut, Hex (#8-32)	10	098-6561	1	Label, Operation
5	853-0005	2	Washer, Lock - ÉT (#8)	· 11	308-0955	1	Switch, Selector (S14)
6	526-0003	2	Washer, Flat (#8)	12	308-0989	A/R	Key, Replacement

Sequencer




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1			Board, PC - Sequencer	4	870-0131	4	Nut, Hex w/ET (#10-32)
	300-3893-01	1	12 Volt	5	815-0550	4	Screw, Pan Head - Cross
	300-3893-02	! 1	24 Volt				Recessed w/ET (#6-32 x 3/8)
2	319-1208	1	Plate, Mounting - Sequencer	6	332-0942	20	Tie, Cable
3	332-2420	10	Mount Tie - Cable				

Monitor




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-097600	1	Plate, Relay	4	332-0941	15	Tie, Cable
2			Relay, Monitor	5	815-0544	6	Screw, Round Head w/IT
	307-2801-01	1	240 VAC				(#6-32 x 1/2)
	307-2801-02	1	380 VAC	6	332-0801	3	Terminal, Ring (#6)
	307-2801-03	1	480 VAC	7	332-2630	7	Terminal, Spade (#6)
3	332-2420	5	Mount Tie - Cable				•

Pins and Sockets




Cabinet (Set Mounted Switch)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	319-2333	1	Door, Cabinet	8	332-2839	2	Bracket, End
2	098-5387	1	Label, Danger	9	332-2836-02	2 1	Block, Terminal - Sectional
3	302-1984-04	2	Transformer, Current	10	332-2841	1	Plate, End – Terminal
4	870-0131	4	Nut, Hex – W/ET (#10)	11	332-2842-23	3 1	Tag, Terminal (101 - 110)
5	319-2483-01	1	Cabinet	12	895-0308	20"	Tape - Polyurethane
6	098-6895	1	Label, Alarm	13	895-0172	7"	Tape, Neoprene
7	332-3356	1	Rail, Terminal				


Connecting Hardware (Set Mounted Switch) (Diesel Sets)



539-1603


REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	331-0548	1	Connector, Liquidtite	4	331-0544	5	Washer, Sealing
2	331-0546	1	Connector, Liquidtite (1)	5	331-0543-02	5	Nut, Locking
3	331-0549	1	Conduit, Liquidtite (2' long)	6	870-2055	3	Nut, Lock - Flange (M8 x 1-1/4)

Connecting Hardware (Set Mounted Switch) (20 & 25 kW Gas Sets)




REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	331–0547 331–0550	4 2	Connector, Liquidtite (1–1/2) Conduit, Liquidtite (54" long)	6	815-0858-01	8	Screw, Flange Head (M8 x 1-1/4 x 16)
3	331–0546	2	Connector, Liquiditie (1)	7	331-0544	4	Washer, Sealing
4	331-0549	1	Conduit, Liquidtite (54" long)	8	331-0543-02	4	Nut, Locking
5	508-0210	Δ/R	Grommet Channel Edging				

Transfer Switch (10 kW Gas Sets)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	8950172	-	Tape, Sealing – Bulk (11/16" Thk x 1–1/4" Wide) (Order by the foot – 7 feet required)	5	331–0549	-	Conduit – Bulk – Liquid Tight (1") (Order by the foot – 2 feet required)
2	895-0308	-	Tape, Sealing Bulk (1/8" Thk x	6	331-0544	5	Washer, Sealing
			1" Wide) (Order by the foot – 2 feet required)	7	331-054302	5	Nut, Locking – Liquid Tight (1/2")
3	331–0548	1	Connector, Elbow – 90 Deg – Liquid Tight (1")	8	870–2055	3	Nut, Locking – Flange Head (M8)
4	331-0546	1	Connector Liquid Tight (1")				, ,

Circuit Breakers (Set Mounted Switch)



REF NO.	PART NO.	QTY USED	PART DESCRIPTION	REF NO.	PART NO.	QTY USED	PART DESCRIPTION
1	320-1841-39	1	Breaker, Circuit - Main	4	319-2343-01	1 1	Bracket, Mounting - Circuit
2	320–1140	1	Breaker, Circuit - Heaters				Breaker
3	812-0060	4	Screw, Machine - Round Head	5	098–6879	1	Label, Circuit Breakers
			(#632 x 5/16)	6	870-0232	2	Nut, Hex – W/ET (1/4)

Numerical Index

Part No. Page	Part No. Page	Part No. Page	Part No. Page
098–4339, 28 , 30	300–3160, 28	306–1968, 6	307–2578, 22 , 23 , 37
098–5387, 12 , 14 , 20	300–3244 , 30	306–1972, 6	307–2582, 23
098–5586, 4	300–3261, 10	306–1984, 6	307–2583, 23
098–5589, 12, 14, 20	300–3267, 10	306–1989, 4	307–2591, 35
098–5680, 12	300–3893–01, 38	306–1993, 7	307–2597, 14
098–5681, 12 , 14	300–3893–02, 38	306–1994, 8	307–2600–01, 14
098–5692, 20	300–3998–01, 33	306–1995, 8	307–2648, 12 , 14
098–5693, 20	300–3998–02, 33	306–1996, 6 , 8	308–0406, 12 , 14
098–5694, 20	300–4054, 36	306–2013, 5 , 6	308–0848, 18
098–5695, 20	301–6727, 20	306–2017, 6	308–0849, 18 , 22
098–5699, 12, 14	301–9754, 12	306–2031, 6	308–0850, 18 , 22
098–5708, 26	301–9760, 20	306–2032, 6	308-0851, 22
098-5710, 21, 24, 31, 34, 36	301–9766, 18	306–2178, 6	308–0854, 18
098–5734, 14	301–9768, 32	306–3384, 4	308–0886, 22
098–5773, 12	301–9774, 12 , 14	306–3391, 7	308–0904, 20
098–5777–01, 20	301–9806, 20	306–3392, 5 , 7	308–0905, 20
098–5807, 28	301-9928-01, 35	306–3393, 5 , 7	308–0955, 22 , 37
098–5808, 28	301–9928–02, 35	306–3394, 4	308-0957, 22 , 37
098–5809, 28	301–9932, 31	306–3395, 4	308–0988, 22
098–5914, 30	301–9961, 12 , 14	306–3397, 5	308-0989, 18 , 22
098–5915, 30	301–9990, 26	306–3398, 7	308–0990, 22
098–5916, 30	301–9992, 26	306–3399, 5	308–0991, 18
098–5995, 28	302–0807, 26	306-3400-01, 4	308–0992, 18
098–5996, 28	302–1175, 18	306–3401–01, 4	308–0993, 18
098– 5997, 30	3021678, 20	306-3401-03, 4	308–0994, 18
098–5998, 30	302–1692, 18	306–3401–05, 4	308–0997, 18
098–6039, 28	302–1710, 18	306-3401-06, 4	309–0393, 7
098–6561, 22 , 37	302–1711, 18	306–3403, 5	312-0203, 4
098–6635, 20	302 – 1720, 18	306–3404 , 4	312-0228, 4
098–6697, 22	302–1805–01, 20	306–3464, 18	312-0257-01, 4
300–2946, 26	302–1805–02, 20	306–3465, 20	312-0257-02, 4
300–3090, 10	302–1844, 28, 30	306–3466, 20	312-0257-03, 4
300 – 3092, 10	304–0015, 26	306–3470, 10	315-0621-01, 26
300 – 3093–01, 10	304–0037, 26	306–3485–01, 2	315-0621-02, 26
300–3093–02, 10	304–0139, 26	306–3485–03, 2	315–0621–03, 26
300–3 094, 10	305–0653, 28 , 30	306–3485–04, 2	315-0621-04, 26
300–3095, 36	305–0781, 28, 30	306–3485–05, 2	315–0655–01, 12
300–3096, 31	306–1961, 6	306–3485–06, 2	315–0655–02, 12
300– 3115–01, 35	306–1962, 6	306–3495, 6	315–0655–03, 12
300–3115–02, 35	306–1964, 6	306–3525, 20	315–0655–04, 14
300–3118, 10	306–1965, 6	306–3980, 10	315–0662, 14
300–3119, 10	306–1966, 6	307–2575, 12	315–0665, 28
300–3121, 10	306–1967, 6	307–2577, 32	315–0667, 28

Numerical Index

Part No. Page	Part No. Page	Part No. Page	Part No. Page
315–0669, 28	321–0174, 31	332–0802, 22, 23, 37	338–2012, 5
315–0671, 28	321–0175, 26	332–0941, 22 , 24	338–2062, 12
315–0673, 28	321–0236, 28	332–0942, 4 , 22 , 24 , 26 , 28 ,	338–2063, 18
315–0675, 28	321–0237, 28 , 30	30, 31, 32, 33, 34, 35, 36, 38	338–2071, 12
315–0677, 28	321–0304–01, 28	332–1348, 20	338–2072, 14
315–0679, 28	321–0304–02, 28 , 30	332–1877, 10	338–2096, 12
315–0701, 30	321–0304–03, 28, 30	332–1917, 10	338–2097, 12
315–0703, 30	321–0304–04, 28 , 30	332–2230, 23 , 33 , 34 , 37	338–2098, 14
315–0705, 30	321–0304–05, 28 , 30	332–2352, 5	338–2133, 18
315–0707, 30	321–0304–06, 30	332–2366, 5 , 6	338–2134, 18
315–0709, 30	322–0137, 18	332–2370, 5	338–2135, 18
315–0711, 30	322–0168, 18	332–2420, 22, 26, 28, 30, 38	338–2139, 35
315–0713, 30	322–0170, 18	332–2605, 4	338–2141, 31
315–0715, 30	322–0387–02, 18	332–2777, 26 , 28 , 30	338–2142, 36
315–0731, 20	323–0983, 40	332–2832, 4	338–2149, 26
319–0002, 12	323–0984, 40	332–2834, 5	338–2161, 26 , 28 , 30
319-0009, 14	323–1158, 40	332–2835, 6	338–2204–01, 20
319–0072, 28 , 30	323–1194, 40	332–2836–01, 34	338–2204–02, 20
319–0073, 28 , 30	323–1195, 40	332–2836–02, 24 , 31 , 36	338–2204–03, 20
319–0124, 20	323–1199, 40	332–2837–09, 21 , 24 , 3 1,	338–2205–01, 20
319-0143-01, 20	323–1200, 40	34, 36 332–2839, 21, 24, 31, 34, 36	338220502, 20
319-0143-02, 20	323–1206, 40	332–2841, 21 , 24 , 31 , 34 , 36	338–2205–03, 20
319-0143-03, 20	323–1207, 40	332–2842, 21 , 31	338–2223, 28 , 30
319–0143–04, 20	323–1208, 40	332–2842–11, 36	338–2337, 12 , 14
319–0145, 20	323–1252, 40	332–2842–13, 31	338–2349, 24
319-0146, 20	323-1253, 40	332–2842–15, 24	338–2949, 26 , 28 , 30
319–0152, 18	323-1291, 40	332–2842–16, 34	338–2983, 26 , 28 , 30
319-0362-01, 20	323–1292, 40	332–2876–01, 21	338–2987, 36
319–0362–02, 20	323–1314, 40	332–2877, 20	406–0519, 20
319-0362-03, 20	323–1315, 40	332–2878, 23 , 37	406–0610–02, 20
319-0362-04, 20	323–1316, 40	332–2879–02, 23 , 37	406–0610–03, 20
319–0363, 18	323–1317, 40	332–2880, 5	406–0610–04, 20
319-1176-01, 20	323–1318, 40	332–2884, 12 , 14	406–0613, 18
319-1178-01, 20	323–1325, 40	332–2903, 4	406–0649, 18
319–1208, 38	323–1333, 20 , 40	332–3084, 5	508–0231, 20
319–1429, 18	323–1387, 10	332–3085, 6	5080233, 20
319–1502, 36	323–1408, 36	334–1842, 23	508–1045, 20
320–0606, 4	323–1409, 31	337–2313, 5	517–0137, 18
320–0608, 4	331-0543-02, 44	337–2314, 5	517–0256, 10
320-0876, 4	331–0544, 44	337–2315, 5	517–0266, 20
321–0104, 28 , 30	331–0546, 44	337–2316, 5	518–0404, 20
321-0127, 28 , 30	3310548, 44	337–2317, 5	525–0305, 20
321–0153, 26	331–0549, 44		
	and the second s		

Numerical Index

Part No. Page	Part No. Page	Part No. Page	Part No. Page
Part No. Page 526-0002, 6 526-0003, 23, 37 526-0008, 4, 5 526-0018, 4, 5 526-0022, 20 526-0048, 6, 12, 14 532-0374, 22 539-1344, 33 800-0003, 5 800-0004, 5 800-0006, 33 800-0008, 4 810-0085, 12, 14 812-0061, 32 812-0068, 8 812-0068, 8 812-0177, 20	815-0029, 4 815-0180, 5 815-0221, 20 815-0388, 6 815-0446, 22 815-0527, 6 815-0538, 5, 14 815-0539, 6, 12 815-0544, 10, 12, 14, 20 815-0549, 26 815-0550, 14, 26, 28, 30, 35, 38 815-0555, 12 815-0651, 4 815-0652, 4, 5, 20 815-0680, 35 815-0680, 31, 36	821-0028, 4, 20 821-0040, 12, 14, 26, 28, 30 822-2048, 28, 30 822-2049, 28, 30 850-0020, 6 850-0030, 5 850-0040, 4, 5, 33 851-0027, 5 851-0031, 5 853-0005, 23, 37 853-1003, 32 856-0002, 12, 14 860-0008, 12, 14, 23, 37 862-0001, 5, 33 870-0053, 5 870-0131, 4, 12, 14, 20, 26, 28, 30, 32, 38 870-0133, 4	870-0221, 12, 14, 21, 24, 28, 30, 31, 34, 36 870-0281, 20 870-0386, 20 870-0439, 18, 20 870-2055, 44 895-0172, 44 895-0293-01, 20 895-0293-02, 20 895-0293-03, 20 895-0293-04, 20 895-0293-05, 20 895-0293-07, 20 895-0293-07, 20 895-0293-09, 20 895-0293-10, 20 895-0293-11, 20
813–0103, 6 813–0112, 26 813–0116, 26	815–0686, 7 821–0004, 20 821–0005, 4 , 5	870–0134, 20 870–0201, 7 , 8	895–0308, 44 898–0778, 20